






Reset Circuitry




Chip Mode Circuitry




3.3V Caps



USB & SPI



MCU Configuration



DIY – Finn Ganser

Sheet: /MCU/
File: MCU.kicad_sch



Title: DisplayBoard

Size: A4 Date: 2025-10-21

KiCad E.D.A. 9.0.0

Rev: v1.0

Id: 2/5



DIY – Finn Ganser

Sheet: /GC9A01/
File: gc9a01.kicad_sch



Title: DisplayBoard


Size: A4 Date: 2025-10-21

KiCad E.D.A. 9.0.0

Rev: v1.0

Id: 3/5





DIY – Finn Ganser

Sheet: /USB/
File: usb.kicad_sch

Title: DisplayBoard

Size: A4 Date: 2025-10-21

KiCad E.D.A. 9.0.0

Rev: v1.0

Id: 5/5