

## File Destination List

**Put this file:**        **to**    **Destination Folder:**

MTX1394.sys	to	c:\program files\Matrox imaging\drivers\meteor_II_1394\drivernt
mf1394core.sys	to	c:\program files\Matrox Imaging\drivers\meteor_II_1394\drivernt

MTX1394.sys	to	c:\program files\Matrox imaging\drivers\meteor_II_1394\wdm
-------------	----	--

image_mtx.inf	to	c:\program files\Matrox Imaging\drivers\win2000
---------------	----	---

Mil.h	to	c:\program files\Matrox Imaging\intellicam\mil\include
-------	----	--

 Note 1

mil.dll	to	c:\program files\Matrox Imaging\mil\library\winnt\msc\dll
mil1394.dll	to	c:\program files\Matrox imaging\mil\library\winnt\msc\dll

 Note 1

image_mtx.inf	to	c:\%systemroot%\INF
---------------	----	---------------------

 Note 2

mil.dll	to	c:\%systemroot%\system32
mil1394.dll	to	c:\%systemroot%\system32

 Note 2

MTX1394.sys	to	c:\%systemroot%\system32\drivers
-------------	----	----------------------------------

 Note 2

mil.ini	to	c:\%systemroot%\
---------	----	------------------

 Note 2

Note 1: Only necessary if folder already exists.

Note 2: Where %systemroot% is:  
          windows    for Windows XP    or  
          WINNT     for Windows 2000