


Chapter 1 Get started

About the user guide

Thanks for choosing Xiaomi phone, please read the user guide carefully before you start. This is the phone generic user guide for the HyperOS version. If you are not sure which software version your device is running, you can go to **Settings > About phone** to view the HyperOS version information.

For more HyperOS features, see <https://www.mi.com/global/hyperos>.

Phone overview



1. Front camera	2. SIM card slot	3. USB port
4. Fingerprint sensor	5. Power button/Power button with Fingerprint sensor	6. Volume buttons
7. Flash	8. Rear cameras	

Note

The illustration is for reference only. The fingerprint sensor may locate on the **Power button** or at the bottom of the screen.

Insert a SIM card

1. Withdraw the SIM card slot with the ejection tool.