

Series caps (C1/C2) should normally be 1/10 parallel caps (C3/C4) to provide the impedance transformation. Parallel caps mainly determine the resonant frequency.

C7/C8 are primarily used to adjust the resonant frequency in this case.

### ANTENNA MATCHING CIRCUIT

