




DIRT PROOF



SHOCK PROOF




SNOW PROOF



WATER PROOF

OPEN THE CHARGING PORT COVER TO GET A BETTER CALLING



LET'S GO!

The case gives you the freedom to make your electronic device be your constant companion to make sure you're ready to go, follow these steps:

FIRST TIME INSTALLATION

Follow the procedures in this brochure to make sure your waterproof case is ready to go with you everywhere.

Important:prior to water exposure the following procedure must be adhered to:

CHECK SEAL AREA

INSTALLATION

AFTER MAJOR IMPACTS:

It is highly recommended the *First Time Installation* procedure is performed to check the integrity of the case before exposing to water.

ⓘ IMPORTANT ⓘ

Have fun and live free,but remember if an activity could hurt you,it could also hurt your device.The case is a precision piece of equipment.However it is not indestructible and should be used with consideration.The case or device may be damaged by drops from more than tested height - particularly on rough surfaces. We do not guarantee that this case will protect your device in all circumstances.Users expose their device to hazards at their own risk. Users must follow all installation, maintenance and operating instructions carefully for water, dust, and shock protection. Under no circumstances will we repair or replace a damaged device. This case is not a substitute for a back-up or device insurance.

FREEDOM STARTS HERE

Follow these steps to make sure you are ready to experience new freedoms with your electronic device.

CHECK SEAL AREA

✓ Make sure seal area is free of dust, dirt, hair and other debris.





main of seal area

main of seal area

interface sealing plug

WATERPROOF CASE


INSTRUCTIONS




INSTALLATION

1 THOROUGHLY CLEAN YOUR ELECTRONIC DEVICE WITH CLEANING CLOTH.


NOTE: Make Sure to REMOVE Any Screen Protector & Camera Lens Protector Before Installing




2 INSTALL THE ELECTRONIC DEVICE TO THE WATERPROOF CASE.



3 WITH THE BACK FACING DOWN, PRESS FIRMLY ALL AROUND THE CASE TO ENSURE LATCHES ARE COMPLETELY CLOSED ALL THE WAY AROUND.




4 MAKE SURE ALL THE PLUGS ARE SCREWED SECURELY.




REMOVAL


1 OPEN HEADPHONE JACK COVER (IF THERE IS) AND USB PLUG.




2 OPEN THE CASE WITH COIN OR OTHER TOOLS.



3 REMOVE THE COVER FROM BOTTOM TO TOP.



4 REMOVE THE ELECTRONIC DEVICE FROM THE FRAME.



BEFORE USE

You're probably excited about all the new freedoms bring to you, but before you engage in any activities make sure you follow these common-sense rules:

✓ FOLLOW INSTRUCTIONS

Study instructions for correct installation.

✓ MAKE SURE IT'S ALL SEALED

Ensure all ports and seams are closed tightly.

✓ BACK-UP YOUR DATA REGULARLY

If you are going to engage in activities where there may be potential damage to the device, ensure you have backed up your data.

✓ BE SENSIBLE

Your waterproof case is a precision piece of equipment, it is sleek, it is tough, but it's not indestructible.Use it sensibly.

DAILY MAINTENANCE

EVERYDAY CARE CHECKLIST

Follow this checklist to make sure your waterproof case protects your electronic device everywhere you go.

✓ RINSE WITH FRESH WATER AFTER USE

Rinse case thoroughly with fresh water after exposure to chemicals including soap,detergents, and chlorine.

✓ CHECK SEALS AFTER MAJOR IMPACTS

After major drops or impacts, inspect case for any damage and ensure all seams are closed, see checklist below.

IF A MAJOR IMPACT OCCURS, FOLLOW THESE STEPS:

✓ Check that front and back of case has not come apart at any point and all seals are tightly closed

✓ Check headphone jack (if there is) cover and USB plug is still screwed in.

