

FEATURE LIST:

- selector Relative and Absolute coordinate
- set Keyboard events for the up-to 24 macrokeys
- set an active area,
- set min/max pressure
- set jittering: threshold (delay) on X & Y values
- set X-Tilt and Y-Tilt
- Wheel reports

CONFIG FILE NOTE

XFree86:
/etc/X11/XF86Config or /etc/X11/XF86Config-4
X.Org:
/etc/X11/xorg.conf.

SAMPLE :

```
Section "InputDevice"
    Identifier "pen"
    Driver      "aiptek"
    Option      "Device"    "/dev/input/aiptek"
    Option      "Type"       "stylus"
    Option      "Mode"       "absolute"
    Option      "Cursor"     "stylus"
    Option      "USB"        "on"
    Option      "KeepShape"  "on"
    Option      "debuglevel" "20"
EndSection
```

```
Section "InputDevice"
    Identifier "cursor"
    Driver      "aiptek"
    Option      "Device"    "/dev/input/aiptek"
    Option      "Type"       "cursor"
    Option      "Mode"       "absolute"
    Option      "Cursor"     "puck"
    Option      "USB"        "on"
    Option      "KeepShape"  "on"
    Option      "debuglevel" "20"
EndSection
```

```
Section "InputDevice"
    Identifier "eraser"
    Driver      "aiptek"
    Option      "Device"    "/dev/input/aiptek"
    Option      "Type"       "eraser"
    Option      "Mode"       "absolute"
    Option      "Cursor"     "stylus"
    Option      "USB"        "on"
    Option      "KeepShape"  "on"
    Option      "debuglevel" "20"
EndSection
```

```
Section "ServerLayout"
    Identifier "A Layout"
    Screen      "A Screen"
    InputDevice "A Keyboard"
    InputDevice "A Mouse"    "CorePointer"
    InputDevice "pen"        "AlwaysCore"
    InputDevice "cursor"     "AlwaysCore"
    InputDevice "eraser"     "AlwaysCore"
EndSection
```

TABLET AREA COORDINATE

