



Lisa Keyboard Reference Card Replacements | Card 1: LisaNotes

Created by Rocky Bergen (rockybergen.com) - Reformatted by Andrew Yaros (yaros.ae)



Lisa Keyboard Reference Card Replacements | Card 1: Keyboard
Created by Rocky Bergen (rockybergen.com) - Reformatted by Andrew Yaros (yaros.ae)



Lisa Keyboard Reference Card Replacements | Card 2: Icons

Created by Rocky Bergen (rockybergen.com) - Reformatted by Andrew Yaros (yaros.ae)

Apple, the apple logo and Lisa are trademarks of Apple Computer, Inc.

815-4102-A

Icons


Select one:

- Click in icon.



Select several:

- Hold and move to form box around icons. OR
- Click in first icon.
- (Shift)-click in others.




Select all icons in window:

- Activate window.
- Choose **Select All Icons** from **Edit** menu.

Note For more information see your Lisa Owner's Guide.

Deselect one:

- (Shift)-click in icon.



Deselect all:

- Click on desktop.

Open:

- Click twice rapidly.



Move:

- Hold button down and move.



Create document (or folder):

- Click twice rapidly on stationery pad icon.
- Type document name.
- Click twice rapidly to open new document.



File:

- Move icon to a folder or disk.



Discard:

- Move icon to Wastebasket. (To retrieve, open Wastebasket and move icon out.)



Duplicate:


- Select icon.
- Choose **Duplicate** from **File/Print** menu.
- Move blinking icon.

Create stationery pad:

- Select icon.
- Choose **Make Stationery Pad** from **File/Print** menu.

Backup disk:

- Move icon to disk.




Apple, the apple logo and Lisa are trademarks of Apple Computer, Inc.

815-4103-A

Windows

Close:

Click twice rapidly in the bar icon.



Scroll line by line:

Click or hold in arrow.

Scroll quickly:

Hold and move elevator.

Scroll by windowful:

Click or hold in view button.

Print:

Activate document window and choose **Print** from **File/Print** menu.

Resize:

Hold and move size control box.

Text

Select insertion point:

- Place **I**-pointer and click.

Insert:

- Select insertion point, type.

Select text:

- Hold and move through text.

Replace:

- Select text, type.

Delete:

- Select text.
- Choose **Cut** from **Edit** menu, OR
- Press the **Backspace** key.

Move text:

- Select text.
- Choose **Cut** from **Edit** menu.
- Select new location.
- Choose **Paste** from **Edit** menu.

Copy text:

- Select text.
- Choose **Copy** from **Edit** menu.
- Select new location.
- Choose **Paste** from **Edit** menu.

Correct errors:

- Wrong Selection.
- Start selection over.
- Otherwise:
- Choose **Undo Last Change** from **Edit** menu.

Apple, the apple logo and Lisa are trademarks of Apple Computer, Inc.

815-4104-A



LisaNotes



Configuration Data	Device connections (from Preferences)	Support Information
Expansion 1:		Lisa Serial Number:
Expansion 2:		Support Contract Expiration Date:
Expansion 3:		Support Center Phone Number:
Parallel:		Notes:
Serial A:		
Serial B:		