

CR Touch Firmware Version for 32-bit Motherboard

Model	Condition 1	Condition 2	Firmware Version
Ender-3	4.2.2 32-bit Motherboard Firmware	CR Touch without Adapter Board	Ender-3- Marlin2.0.1 - V1.1.2 - ALT
	4.2.7 32-bit Motherboard Firmware	CR Touch without Adapter Board	Ender-3- Marlin2.0.1 - V1.1.2 - ALT - TMC2225
Ender-3MAX	4.2.2 32-bit Motherboard Firmware	CR Touch without Adapter Board	Ender-3 Max - V1.0.1.6 - ALT
	4.2.7 32-bit Motherboard Firmware	CR Touch without Adapter Board	Ender-3 MaxMarlin2.0.6HW4.2.7ALT
Ender-3Pro	4.2.2 32-bit Motherboard Firmware	CR Touch without Adapter Board	Ender-3 Pro- Marlin2.0.1 - V1.1.2 - ALT
	4.2.7 32-bit Motherboard Firmware	CR Touch without Adapter Board	Ender-3 Pro- Marlin2.0.1 - V1.1.2 - ALT - TMC2225
Ender-3V2	4.2.2 32-bit Motherboard Firmware	CR Touch without Adapter Board	Ender-3 V2_Marlin2.0.8_HW_V4.2.2_SW_V2.0.8.4_ALT_Zh_CN_en_20210715
		CR Touch+Filament Sensor	Ender-3 V2-Marlin-2.0.1-HW-4.2.2-mainboard-V1.1.2-Compatible with ALT and filament detection
	4.2.7 32-bit Motherboard Firmware	CR Touch without Adapter Board	Ender-3 V2_Marlin2.0.8_HW_V4.2.7_SW_V2.0.8.4_ALT_Zh_CN_en_20210802
		CR Touch+Filament Sensor	Ender-3 V2-Marlin-2.0.1-HW-4.2.7-mainboard-V1.1.2-compatible with ALT and filament detection
Ender-5、5S	4.2.2 32-bit Motherboard Firmware	CR Touch without Adapter Board	Ender-5- Marlin2.0.1 - V1.1.1 - ALT
	4.2.7 32-bit Motherboard Firmware	CR Touch without Adapter Board	Ender-5- Marlin2.0.1 - V1.1.1 - ALT - TMC2225
Ender-5Pro	4.2.2 32-bit Motherboard Firmware	CR Touch without Adapter Board	Ender-5 ProMarlin2.0.6HW4.2.2ALTE137
	4.2.7 32-bit Motherboard Firmware	CR Touch without Adapter Board	Ender-5 Pro- Marlin2.0.1 - V1.1.1 - ALT - TMC2235
CR-10	4.2.7 (32-bit Silent Motherboard)	CR Touch without Adapter Board	CR-10-Marlin2.0.1-20201207-HW-V4.2.7-SW-V1.1.1 ALT-English
Ender-5plus	CR Touch Firmware	CR Touch Firmware	Ender-5PlusALT_0904_V1.70.2 BL.hex
Ender-6	CR Touch Firmware	CR Touch Firmware	Ender-6-V1.0.4.9-ALT
Ender-7	CR Touch Firmware+Touchscreen Firmware	CR Touch Firmware+Touchscreen Firmware	Ender7_HW-2.4.S1.101_SW-1.0.3T-ALT DWIN_SET
Note: Creality will launch the newest firmware version on www.creality.com/download. Please download the corresponding firmware on official website.			