

## **1-Activities in StartPreOS Sequence**

Callout EcuM\_AL\_SetProgrammableInterrupts  
Callout EcuM\_AL\_DriverInitZero  
Callout EcuM\_DeterminePbConfiguration  
Check consistency of configuration data  
Callout EcuM\_AL\_DriverInitOne  
Get reset reason  
Select default shutdown target  
Callout EcuM\_LoopDetection  
Start OS

## **2-Activities in the OffPreOS Sequence**

De-init BSW Mode Manager  
De-init BSW Scheduler  
Check for pending wakeup events  
Set RESET as shutdown target, if wakeup events are pending  
ShutdownOS