


Build your own RTMP data source

Aug 06, 2018

Aixi Wang

Data flow



Configure Onvif/RTSP camera

- Set your username/password according to user manual

configure RTMP push



192.168.2.112/OutputP1Main.html



RTMP Server

- `docker pull jasonrivers/nginx-rtmp`
- `docker run -p 1935:1935 -p 9090:8080 jasonrivers/nginx-rtmp`

Client

