



1 CLEAR beamline layout drawings

This file is used to generate the “split” drawings, 1 A4 page wide. When tikzexternalize is on, output is saved to folder outputLayout_unbroken. See README.md for more information.

1.1 All text ON, show legend



1.2 Simplified (no distances or element names)



1.3 Beamline only (no distances, element names, RF, or laser)

