



Programming pinout

VDD	=	3.3V via regulator from USB
USB-Rx	=	To ESP board Tx
USB-Tx	=	To ESP board Rx
Circuit 1	=	To ESP board GPIO0
Circuit 2	=	To ESP board Reset

Nodemcu programming  
ciscuit for Reset and GPIO0