

# WeatherStation

## SOFTWARE USER GUIDE

### Live Mode

1. Click on File -> Live
2. Choose different Views from View -> (Digital/Analog/Stripchart)
3. For saving the live data, click on Stop, then click on File -> Save

### Save Mode

1. Click on File -> Save
2. This will open a dialog box
3. Choose an appropriate name for the save file
4. Click on Save
5. A file named <filename>.CSV will be saved on the desired path on disk

### Load Mode

1. Using the dialog box, find a compatible .CSV file saved earlier through software
2. Choose the file, then click on Load
3. This will now load the values from the chosen file into the software
4. Choose different Views from View -> (Digital/Analogue/Stripchart)

### Views

1. Three view modes - Digital, Analogue and Stripchart
2. Digital view displays the numerical values of the desired data
3. Analogue view displays bar charts for Wind speed, Temperature and Ligh Insolation
4. Stripchart view displays a moving paper display with superimposing  
Temperature, Wind speed and Light Insolation