



NWC BATCH EXPORT

USER GUIDE VERSION 2015.0.0.1

Batch it then clash it

Contents

INTRODUCTION.....	2
Benefits	2
Demonstration Video	2
INSTALLATION.....	2
USER INTERFACE	3
STEPS.....	4
Folder Path	4
Select Views	4
Export Options	4
Exportation Progress	4
SUPPORT	5
Support contacts	5



INTRODUCTION

The NWC Batch Export is a tool by BIM One that helps you export your 3D views in batch to a predefined folder. Instead of having to go through the classic export process for each and every view, you can simply select multiple views at once and let the plugin do the rest.

Benefits

- Time saving
- Constant export through NWC files
- Naming convention is dealt within Revit


Demonstration Video

INSTALLATION

Please refer to the [BIM One Add-Ins Manager® user guide](#) for installation/update process for our Revit Add-ins.



USER INTERFACE



1. Folder path and Browse button
2. Views Selection
3. Quick Selection Options
4. Export Options
5. Begin NWC Export

STEPS

Folder Path

Folder Path:


Browse

Select Views

View(s) to Export:

- ☐ 3D-Columns
- ☐ 3D-Doors
- ☐ 3D-Framing
- ☐ 3D-Rated Walls
- ☐ 3D-Windows

Export Options

 **Navisworks Options** ✕

Convert construction parts ☐

Convert element ids ☒

Convert element parameters

All ▾

Convert element properties ☐

Convert linked files ☒

Convert room as attribute ☒

Convert URLs ☒

Coordinates

Internal ▾

Divide File into Levels ☐

Export

View ▾

Export room geometry ☒

Try and find missing materials ☒

Default

Close

Exportation Progress



App Version 2015.0.0.1

www.bimone.com

SUPPORT

Support contacts



Send us a description of your issue at:

support@bimone.ca

48h follow-up guaranteed

