


Everything you
need to know about
the LiFi Starter Pack.

What is Included?




2x

LiFi-XC Stations

USB (2.0) dongle that fits into device to send and receive data, to and from Access Point

[Download the data sheet](#)



2x

LiFi-XC Access Points
& TX Drivers

Connects to the LiFi-enabled lights to send & receive data

[Download the data sheet](#)



2x

Lucicup II Luminaires

LiFi compatible lights

[Download the data sheet](#)

What is not Included?

We offer the fundamental elements that are required to build a LiFi network but additional equipment is required:




Router

Requires I.P. Address Assignment Capabilities



uPoE / PoE+ Switch

Requires 25 Watt per device per port



Ethernet Cables

CAT5 or CAT6

What Else?

Your fully networked, full-duplex, wireless LiFi system includes drivers compatible with Linux & Windows devices.

The system can be deployed through PoE or using a standard mains powered solution. We recommend deploying using PoE+ (30 watt) to minimise the cabling required.

Please Note:

No personal support is available for the starter kit, but a set-up manual & test guide are included.

(If you decide to deploy your system using a mains powered solution, an appropriate, certified power supply can be purchased from pureLiFi at an additional cost).

What to do next?

Let our pureLiFi team member know you would like to proceed and we will send you a proforma, to complete.

