


B A R C O D E R E A D I N G

CONFIGURATION GUIDE



CR5000



codecorp.com



User Manual



codecorporation

Expect More.

code[®]

Table of Contents

NOTE: Configuration changes will take effect immediately and be saved to memory.

A1

A2

A3

A4

B1

B2

B3

B4

C1

C2

C3

C4

D1

D2

D3

D4

E1

E2

E3

E4

