


# USER MANUAL


**CONCEALED CISTERN** Bathroom space optimization

Hidden Brilliance. Visible Elegance


# SCOPE OF SUPPLY




## 1. DIMENSIONAL SPECIFICATION




## 2. Technical Specification Of Wall Hung Toilet




### 3. Installation Mode




### 4. Install The Water Inlet Pipe




### 5. Install Drain Pipe




6. Paving




7. Install Flush Plate



8. Adjust The Toilet Pipe And Sewage Waste Pipe




# 9. Install The Wall Hung Toilet




## A. Drain Valve Troubleshooting

PROBLEM	SOLUTION
No DRAINAGE	Replace the flushing rod
	Adjust the working water level
LEAKAGE	Replace sealing ring
	Replace drain valve



# B. Inlet Valve Maintenance

PROBLEM	SOLUTION
The water level is too high or too low	Adjustment Lever
The water inlet valve is not watertight	Clean the sealing ring and remove debris
Water fills too slow	Clean the filter and increase the water pressure



## CONCEALED CISTERN Bathroom space optimization

**WARNING:** The installation process is the reverse of the teardown procedure. when reinstalling the valve after cleaning or replacement, ensure it is carefully aligned to its original orientation and configuration.

