

Quick Start Guide v2.1



Thank you for purchasing **Arcanus 55**. We are glad to help you get started. Please contact our support team if you have any questions.

support@arcanus55.awsapps.com

Welcome | Unpacking Arcanus 55

Your Arcanus 55 package may contain the A55 USB device inside the A55 Capsule. The A55 Capsule will be holographically sealed to prevent tampering. Twisting the top of the capsule will break the seal and then you can remove the A55 USB device.

Contents


Quick Start Guide (this document)
A55 USB device (one or more)
A55 Capsule (one or more)
Gold Key









Create a new Secret PIN | Think of a secure password

The first step is to create a **New** Secret PIN. Please think of a number that only you would know. A number you that you will not forget. This number must remain secret.

Between 6 and 32 numbers
No repeat number (like 1111...)
No consecutive numbers (like 1234 or 4321)
No telephone numbers
No birth dates
No Social Security Numbers



Create your new Secret PIN:

1. Press the power button () to turn on.
2. Press the key button ( ) twice.
3. Enter the *temporary* PIN **655353** then press the key button () to confirm.
4. Enter your new Secret PIN then press the key button () to confirm.
5. Enter your new Secret PIN *again* then press the key button () to confirm.



Note: If you've made a mistake you can go back to Step 1.

Format the USB Device:

When you insert the USB Device into a Windows computer for the first time it may ask you if you want to format the drive.

Initialize (or Reset) the USB Device (caution)

Note: This will completely erase all data and reset to factory defaults.

1. Press the power button () to turn on.
2. Press and hold the key button () and the number **9** until the blue light stops blinking (10 seconds).
3. Press the number **0** (zero).
 - The PIN will be reset to the *factory* default **111111** (six ones).
 - The USB device must be reformatted.

Best Practices | USB Safety Tips

Enter The PIN before inserting the USB into its slot. Do not enter the PIN while the device is connected.

Close all applications before hibernating, suspending, logging off or ejecting the USB device. This is an important step especially if you are using a software cryptocurrency wallet, KeePass or Key Quest Vault.

Put the USB Device back in its capsule when not in use. You should remember to seal the capsule and store it in a safe place.

Make sure you are not being watched or recorded by a surveillance camera. Be aware of your surroundings and look behind you.

Do not plug the USB into a suspicious computer. Avoid using a computer that may be infected with Spyware. If you must use an unknown computer, boot from a Trusted Operating System, and use the Virtual Keyboard to enter passwords.

Do not use a found USB device. If a USB drive magically appears do not plug it into any computer. Be cautious if your USB drive was out of your possession for any period of time.

