

## Mappings with exercise machine support

0001: joystick (unified slider)
0010: joystick (2 sliders), 0.64x rot
0011: Jetset Radio joystick
0100: WASD
0101: Arrows + Ctrl/Space
0110: Arrows + Space/Back
0111: QBert (A=1, B=2)
1000: Dance pad Minecraft
1001: joystick, 1.5x rot
1010: joystick, 2x rot
1011: joystick, dir. switch slider
1100: Arrows + Z/X
1101: XBox 360
1110: Dual joystick

## Mappings without exercise machine support

0001: joystick (unified slider)
0010: joystick (two sliders)
0011: Jetset Radio joystick
0100: WASD
0101: Arrows + Ctrl/Space
0110: Arrows + Space/Back
0111: QBert (A=1, B=2)
1000: Dance pad Minecraft
1001: Arrows + Z/X
1010: XBox 360
1011: Dual joystick