

# Install openni\_tracker

viernes, 8 de julio de 2016 02:08 p. m.

First Install KINECT drivers as described in last page: [Install Kinect Drivers](#).

Make sure to install NITE drivers 1.5.2.23 as described in point (5) of last page as follows:

## Step 5: Install NITE 1.5 (optional)

Firstly, you need to obtain NITE 1.5.2. Go to the following link and download NITE 1.5.2 for your platform..

<http://www.openni.org/openni-sdk/openni-sdk-history-2/>

Extract the archive, and run the installer:

Shell

```
1 sudo ./install.sh
```

At some point, you may be asked for a license key. A working license key can be found just about anywhere on the Internet. I don't think PrimeSense care, or maybe this is a non-commercial license or something. But whatever, just copy that license into the console, including the equals sign at the end, and NITE will install just fine.

Download the package found inside <https://github.com/artur84/iteshu>