

MIDI Input

Use the MIDI Input guides below to find out what MIDI data to send the QuNeo to control the LEDs remotely. See the Remote LED Control chapter of the Full manual for more information.

Drum Mode - All presets use **Channel 1** as the default LED channel for Pads in drum mode and all other sensor types:

QuNeo Drum Mode LED Map. All factory presets default to Channel 1

