


Flash Firmware to LCD Tutorial for Windows (Current Monitoring System (Ver. C 1.09))



1. Unplug LCD screen from PCB board
2. Hold Down BOOT Button
3. Plug in your PC's USB-C cable into LCD Screen
4. Release BOOT Button
5. Click Flash_LCD file to flash firmware