


model_car.ino
Arduino Code



Radio Receiver
(PWM from remote
controller for steer, throttle,
button mode)

PIN_BUTTON_IN 12
PIN_SERVO_IN 11
PIN_MOTOR_IN 10
pin change interrupt

PIN_SERVO_OUT 9

Steer Servo

Drive Motor

PIN_MOTOR_OUT 8

