



# Computer Disassembly, Reassembly & Labeling

By Jeanne Basayo and Nijhai Williams

# Computer Chassis

- This is the First step into decomposing the PC. Remove the Case



# Disk~Top

- Remove 2 Chords. **SATA POWER** & **SATA DATA**





# Sand Disk or The SSD

- Remove 4 screws attached to it



# SATA DATA & POWER CHORD

Remove the chords from both the  
Motherboard and the DVD  
Drive/Disk reader



# POWER BUTTON

- Remove the **Power Button Chord** that Connects to the Mother Board




# Audio Ports Plugs

- Remove the Audio Ports Plugs that Connects to the Motherboard



# POWER SUPPLY

- Remove the **Power Supply Connectors** from the Motherboard





# The Mother Board

- Here is the Mother Board in full



# The Finished Project



REASSEMBLED

3:39

Wednesday, August 21

ViewSonic