


B1-SE-PLUS U Disk Usage Tutorial

1, Use the memory card to update the firmware in BTT mode or MARLIN mode, and copy the firmware.bin in the folder to the memory card. Click Reset to update the firmware.



2, If the U disk cannot be used, open the bottom shell of the machine after power off



3, Insert the jumper cap used for the USB flash drive and wifi selection on the USB flash drive function, as shown in the figure below

