



Core Item #	Core Description
RM1-1082	HP 4240/4250/4350 Fusing Assembly
E6B67-67901	HP M604/M605/M606 Fusing Assembly
F2G68-67901	HP M604/M605/M606 Optional 500 Sheet Paper Input Tray Feeder Assembly
RM1-8808	HP M401/M425MFP Fusing Assembly
RM2-5679	HP M501/M506/M527MFP/M527CMFP Fusing Assembly
RM2-5399	HP M402/M403/M426MFP/M427MFP Fusing Assembly
RM1-8395	HP M601/M602/M603 Fusing Assembly
C1N54-67901	HP CLJ M855/M880MFP Fusing Assembly
Q2439B	HP 4200/4250/4300/4350 Duplexer Assembly
Q2440B	HP 4200/4250/4300/4350 Optional 500 Sheet Assembly
RM2-6454	HP CLJ M377MFP/M452/M477MFP ITB Assembly
RM2-6460	HP CLJ M377MFP/M452/M477MFP Fusing Assembly - Duplex (RM2-6418)
CE710-69009	HP CP5225 Fusing Assembly
CF379-60003	HP CLJ M477FDWMFP Formatter Board
CF288-60029	HP M425MFP ADF Assembly with Hinges
RG5-6848	HP CLJ 5500 Fusing Assembly
RM2-5476	HP CLJ M375MFP/M475MFP/M476MFP Fusing Assembly
B5L47-67906	HP M527/CLJ M577DN/F MFP ADF Assembly
CB518-67901	HP P4014/P4015/P4515 Optional 500 Sheet Feeder
RM1-0865	HP 3015/3020/3030 Fusing Assembly
RM2-6560	HP CLJ M552/M553/M577MFP ITB Assembly
RM1-0047	HP 4200 Cartridge Access Door Cover



RM1-6740	HP CM2320MFP/CP2020/CP2025 Fusing Assembly (RM1-6738)
CC483-67907	HP CM3530MFP ADF Assembly
C8055A	HP 4000/4050/4100 Lower Cassette Assembly
RG5-5659	HP 9000 Delivery Drive Assembly
RG5-5681	HP 9000/9040/9050 Paper Input Unit
40X7743	Lexmark M51XX/MS81X/MX71X/MX81X Type 00 Fuser Assembly
RG5-2643	HP 4000/4050 Paper Feed Guide Assembly
RG5-2663	HP 4000/4050/4100 Top Cover Assembly
RG5-5646	HP 9000/9040/9050 Left Door and Diverter Assembly
CB414-67928	HP M3027MFP/M3035MFP ADF Assembly - Letter Size
RG5-6476	HP CLJ 4600 500 Sheet Tray
RM2-5177	HP CLJ M351/M451 Fusing Assembly
K0Q14-60002	HP E60055/E60065/E60075/M607/M608/M609 Formatter PCB Assembly
RM1-0114	HP 4300 Toner Access Door
CE794-60001	HP CLJ M351/M451 Formatter Board
RM2-6301	HP M604/M605/M606 Engine Power Supply Assembly
RG5-4811	HP 5000 Laser Scanner Assembly
CF378-60002	HP CLJ M477FDNMFP Formatter Board
B3G84-67912	HP M630MFP/M680/M830/M880MFP Control Panel Assembly
CF367-67920	HP M830MFP/M880MFP ADF Assembly
99A2405	Lexmark T622 Fuser Assembly
115R00076	Xerox Phaser 6600/6605 Fuser Assembly
CB356-67901	HP 1320 Formatter Board - Network



C8053B	HP 4000/4050/4100 Envelope Feeder
PF2282-SVPNR	HP 4345/M4345MFP ADF Assembly
Q1866A	HP 5000/5100 Optional 500 Sheet Feeder Assembly
RG5-7041	HP 5100 Laser Scanner Assembly
RG5-7079	HP 5100 Main Drive Gear Assembly
Q3673-69001	HP CLJ 4600/4650 Optional 500 Sheet Feeder
CF152-60001	HP CLJ M251 Formatter Board - Network
RM2-8062	HP CLJ M252/M274MFP/M277MFP DC Controller - Simplex
RM2-6431	HP CLJ M377MFP/M452/M477MFP Fusing Assembly - Simplex
CF387-60106	HP CLJ M476MFP ADF Scanner Assembly
CF386-60002	HP CLJ M476MFP Duplex Formatter Board - Network
CE863-67901	HP CLJ M476MFP Optional 250 Sheet Tray 3 Feeder w/ Cassette
A2W75-67903	HP CLJ M880MFP Formatter Board
A2W75-67904	HP CLJ M880MFP Scanner Control Board
K0Q14-60001	HP E60055/E60065/E60075/M607/M608/M609 Formatter PCB Assembly - X Models Only (Touch Screen)
CF399-60001	HP M401DNE Formatter Board
C5F92-60002	HP M402 Formatter Board - D Models
D9P29-67018	HP M402/M403/M426MFP/M427MFP Optional 550 Sheet Paper Feeder
F6W13-60001	HP M426MFP Formatter Board - DW Models
F6W14-60002	HP M426MFP Formatter Board - FDN Models
F2A72A	HP M501/M506/M527MFP 1 x 550 Sheet Feeder
RM2-8612	HP M506/M527MFP DC Controller - Duplex
F2A68-67915	HP M506N/DN/DNM Formatter Board



F2A68-67916	HP M506X Formatter Board
CF116-67922	HP M525CMFP ADF Assembly
Q7404-60029	HP M525MFP/M525CMFP/CLJ M575MFP/M575CMFP HR Hinge Assembly
5851-6712	HP M527/CLJ M577MFP/M577CMFP 320GB Secure High Performance Hard Disk Drive
B5L47-67903	HP M527/M527CMFP Scanner Control Board
RM2-6275	HP M604/M605/M606 500 Sheet Feeder Cassette
RM2-6296	HP M604/M605/M606 Paper Input Tray 2 Cassette Assembly
RM2-6787	HP M607/M608/M609/M631MFP/M623MFP/M633MFP Paper Delivery Assembly
B3G86-67901	HP M630MFP ADF Assembly
RM2-9483	HP M631MFP/M632MFP/M633MFP DC Controller Assembly
RM2-9493	HP M631MFP/M632MFP/M633MFP DC Controller PCB Assembly
CF235-67902	HP M712 Formatter Board
RM2-7538	HP M712/M725MFP HVPS
RM1-2963	HP M712/M725MFP/M5025MFP/M5035MFP Fuser Drive Assembly
RM1-9726	HP M806/M830MFP Paper Cassette Tray 2/3
41X0976	Lexmark M51XX/MS71X/81X 550 Sheet Tray
40X7578	Lexmark M51XX/MS71X/81X HVPS
RM1-1307	HP 1320 Front Cover Assembly
RG5-0876	HP 4+/5 Drive Train Gear Assembly
RH7-5295	HP 9000 Controller Board Fan 2
C8085-60551	HP 9000/9040/9050/CLJ 9500 Stapler Stacker Paper Flipper Assembly
RG5-6778	HP CLJ 5500/5550 Front Top Cover Assembly
RG5-6780	HP CLJ 5500/5550 MP Tray Assembly



Q3713-69002	HP CLJ 5550 Formatter Board - Non Network
RM2-5605	HP CLJ M252/M274MFP/M277MFP Main Drive Assembly - Simplex
B3Q11-60001	HP CLJ M274MFP Formatter Board - Network
B3Q11-60001	HP CLJ M274MFP Formatter Board - Network
CF385-60001	HP CLJ M476MFP Formatter Board - Network/Wireless
B5L34-67901	HP CLJ M552/M553/M577MFP 1 x 550 Sheet Feeder Tray Assembly
B5L24-67903	HP CLJ M553 Control Panel Assembly
CZ272-60001	HP CLJ M570MFP Formatter Board - Network
CD646-67901	HP CLJ M575CMFP Image Scanner Assembly
RM1-5001	HP CM3530MFP/CP3525 Fusing Drive Assembly - Simplex
CE490-67902	HP CP5225 Formatter Board
5851-7346	HP E62555/E62565/E62575/M631/M632/M633/M681MFP Scanner Control Board
RM2-9337	HP E62555MFP/E62565MFP/E62575MFP/M631MFP/M632MFP/M633MFP HVPS Assembly
B5L47-67907	HP M527/CLJ M577C/Z MFP ADF Assembly
RM2-7951	HP M527MFP/M527CMFP LVPS
F2G69A	HP M604/M605/M606 Duplexer Assembly
F2G74A	HP M604/M605/M606 Envelope Feeder
RM2-6776	HP M607/M608/M609/M631MFP/M632MFP/M633MFP Transfer Roller Assembly
RM1-8358	HP M60x/M630MFP Drum Motor Assembly
RM2-1318	HP M631MFP/M632MFP/M633MFP LVPS PCB Assembly
RM2-6795	HP M631MFP/M632MFP/M633MFP MP Tray 1 Paper Pickup Roller Assembly
5851-7203	HP M631MFP/M632MFP/M633MFP/CLJ M681MFP ADF Kit
5851-7347	HP M631MFP/M632MFP/M633MFP/CLJ M681MFP/M682MFP/M683MFP Scanner Control Board



J8J61-60001	HP M632/M633MFP Formatter HPCA PC Board
5851-7204	HP M632MFP/M633MFP Document Feeder
J8J64-67901	HP M632MFP/M633MFP Image Scanner with White Backing
RM2-0182	HP M712/M725MFP Tray 2 Pickup Assembly
CZ244-67909	HP M806 Formatter Board - Network
RM1-9883	HP M806/M830MFP 3500 Sheet Crossing Paper Feed Assembly
RC3-3985	HP M806/M830MFP Face Up Tray
RM2-0708	HP M806/M830MFP HCI Paper Pickup Assembly
CF367-67919	HP M830MFP Image Scanner Assembly
56P1443	Lexmark T632 Printhead
RM1-3044	HP 3050/3052/3055 Fusing Assembly
RG5-3526	HP 5000 Paper Feed Belt Assembly
RB2-3558	HP 8100/8150 Left Side Diverter Door
RG5-4360	HP 8100/8150 Top Cover Assembly
RH7-1658	HP 9000/9040/9050/9500MFP Fan 3
C8085A	HP 9000/9040/9050/CLJ 9500 3000 Sheet Stapler/Stacker
C8085-60568	HP 9000/9040/9050/CLJ 9500 Accumulator Assembly
RM1-1740	HP CLJ 4700/CP4005 Tray 1 Assembly
RG5-6736	HP CLJ 5500 Laser Scanner Assembly
B4A21-60002	HP CLJ M252 Formatter Board - Network
RM2-5596	HP CLJ M252 Top Cover Assembly - Simplex
C5F98-60112	HP CLJ M274/277/M426/427MFP ADF and Image Scanner Assembly - Simplex
CF039-60105	HP CLJ M275MFP Input Tray Assembly



CF144-60128	HP CLJ M276MFP ADF/Scanner Assembly
CF144-60130	HP CLJ M276MFP Scanner Assembly
RM1-8544	HP CLJ M351/M375MFP/M451/M475MFP 250 Sheet Cassette Tray 3
CE855-67901	HP CLJ M375MFP/M475MFP Formatter Board
CE863-60119	HP CLJ M375MFP/M475MFP Scanner and ADF Assembly - Duplex
RM2-6560	HP CLJ M552/M553/M577MFP ITB Assembly
B5L24-67909	HP CLJ M553 Formatter Board
CZ271-60024	HP CLJ M570MFP ADF Assembly
CD644-67921	HP CLJ M575CMFP ADF Assembly
CD646-67906	HP CLJ M575CMFP Scanner Control Board
D3L08-67905	HP CLJ M750 Formatter Board
CC522-67922	HP CLJ M775MFP Flatbed Scanner Assembly
RM1-9640	HP CLJ M855/M880MFP Right Door Sub Assembly
CC434-67902	HP CM1312/2320MFP ADF Assembly - Simplex
CC436-67901	HP CM2320NFMFP ADF Assembly - Duplex
CC400-67901	HP CM2320NFXIMFP Duplex Formatter Board - Network
CE522-67901	HP CM3530MFP/CP3525 500 Sheet Feeder Assembly
RM1-7211	HP CP1025/CLJ M175MFP/M275MFP Fusing Assembly
RM1-7916	HP CP5525/CLJ M750/M775MFP Paper Pickup Roller Assembly
RM2-5436	HP M402/M403 Cartridge Door Assembly - NFC Models
RM2-5424	HP M402/M403 Control Panel Assembly - Wireless Models
CF286-60105	HP M425MFP Flatbed Scanner
C5F98-60111	HP M426MFP/M427MFP ADF and Image Scanner Assembly - Duplex



Q7829-60185	HP M5025MFP/M5035MFP Scanner Assembly
RM1-3819	HP M5035MFP Lifter Drive Assembly
A8P79-60115	HP M521MFP Control Panel
RM2-6323	HP M604/M605/M606 MP Tray 1 Pickup Assembly
E6B69-60003	HP M604/M605/M606DN Formatter Board
RM2-6306	HP M605X/M606X Top Cover Assembly
RM2-1248	HP M607/608/609 Transfer Assembly LCD Simplex Model
RM2-1259	HP M607/M608/M609 Control Panel Kit with 4.3 Inch Display Touch Screen
B3G86-67905	HP M630MFP Image Scanner Assembly
RM2-5792	HP M630MFP LVPS
B3G86-67904	HP M630MFP Scanner Control Board
RM2-0849	HP M631MFP/M632MFP/M633MFP Right Door Assembly
5851-7210	HP M632/M633MFP Touch Screen Control Panel
RM1-8662	HP M712/M725MFP MP Cover Assembly
CF066-67906	HP M725MFP Flatbed Scanner Assembly
CF066-67910	HP M725MFP/CLJ M775 ADF Assembly
RC3-3947	HP M806 Control Panel Cover
RM1-9732	HP M806 Face Down Delivery Assembly
RC3-3945	HP M806 Top Right Cover Assembly
99A1576	Lexmark T61X/62X/63X 500 Sheet Tray
40X0232	Lexmark T642/644/646 500 Sheet Redrive Door Assembly
Q2444B	HP 4200/4250/4300/4350 Optional 1500 Sheet Feeder
Q6497-69005	HP 5200 Formatter Board - Non Network





Q5985A	HP CLJ 2700/3000/3600/3800/CP3505 500 Sheet Feeder Assembly
RM1-2750	HP CLJ 3000/3600/3800/CP3505 Paper Output Tray
CF153-60001	HP CLJ M251 Formatter Board - Network/Wireless
RM1-9012	HP CLJ M251 LVPS - Network and Wireless
CF224-60001	HP CLJ M276MFP Formatter Board
RM2-7342	HP CLJ M377MFP/M452/M477MFP Drum Motor
B3Q10-60164	HP CLJ M377MFP/M477MFP ADF Input Tray Assembly
RM2-5469	HP CLJ M476MFP Paper Cassette Tray 2
CF377-60125	HP CLJ M477MFP Integrated Scanner/ADF Assembly - Duplex
RM2-0008	HP CLJ M552/M553/M577MFP Paper Pickup Drive Assembly
CZ271-60015	HP CLJ M570MFP Scanner Assembly
B5L46-67904	HP CLJ M577MFP Image Scanner Assembly
RM1-9360	HP CLJ M775MFP Right Door Assembly
RM2-6856	HP CLJ M855/M880MFP Second Transfer Assembly
CB441-69005	HP CP3505 Formatter Board
CB503-69001	HP CP4005 Formatter Board - Network
CB414-67921	HP M3027MFP/M3035MFP Flatbed Scanner Assembly - Letter Size
RM1-3732	HP M3027MFP/M3035MFP/P3005 500 Sheet Cassette Tray 2
C5F94-60002	HP M402 Formatter Board - DN Models
RM1-5929	HP M4555MFP 1 x 500 Paper Pickup Assembly
RM1-7379	HP M4555MFP 500 Sheet Paper Cassette Tray 2
J8H60-67904	HP M501 Control Panel
RM2-8711	HP M501 DC Controller - Duplex



J8H60-67901	HP M501 Simplex Formatter Board - Network
F2A68-67920	HP M506X Cartridge Door Assembly
CF116-67924	HP M525CMFP Image Scanner
B5L47-67018	HP M527/CLJ M577MFP/M681MFP/M682MFP Control Panel Assembly
G6W84-67902	HP M527MFP 1 GB DDR3 Slim Memory DIMM
B5L26-67901	HP M553X Formatter Assembly
RM2-6310	HP M604/M605/M606 Duplexer Cover Assembly
B5L32-67901	HP M605/M606 eMMC Assembly Kit
RM2-6307	HP M605/M606 Top Cover Assembly
5851-7253	HP M607/608/609N/DN Control Panel Assy 2.7in Display 4 Line W/10 Keys
B3G84-67903	HP M630MFP Duplexer Assembly
RM1-9745	HP M806/M830MFP Paper Pickup Assembly
CZ994-67901	HP M806/M830MFP Stapler/Stacker
40X3243	Lexmark T640/642/644 Optional 500 Sheet Feeder
RM1-1523	HP 2410/2420/2430 MP Tray 1 Cover Assembly
C8054-69001	HP 4000/4050/4100 Duplexer Assembly
RG5-3524	HP 5000 Registration Roller Assembly
RG5-6316	HP 9000/9040/9050/9500MFP ADF Output Tray
C8531-69019	HP 9000/9040/9050/M9040/M9050 2000 Sheet Paper Cassette Tray 4
CE863-60101	HP CLJ M375MFP/M475MFP ADF Assembly - Duplex
RM2-6433	HP CLJ M452NW Top and Control Panel Cover Assembly
CF387-60114	HP CLJ M476MFP Control Panel - DW Only
B5L23-67903	HP CLJ M552 Formatter Board



RM2-7123

HP CLJ M552/M553/M577MFP HVPS - Duplex