

RS-232C Interface

| Pin No. | Symbol | Description |
|---------|--------|---------------------|
| 1 | GND | |
| 2 | TXR | Transmit Data |
| 3 | RXR | Receive Data |
| 4 | RTS | Request to send |
| 5 | CTS | Clear to send |
| 6 | DSR | Data set ready |
| 7 | GND | |
| 8 | NC | |
| 9 | NC | |
| 10 | NC | |
| 11 | NC | |
| 12 | NC | |
| 13 | NC | |
| 14 | NC | |
| 15 | NC | |
| 16 | NC | |
| 17 | NC | |
| 18 | NC | |
| 19 | NC | |
| 20 | DTR | Data terminal ready |
| 21 | NC | |
| 22 | NC | |
| 23 | NC | |
| 24 | NC | |
| 25 | NC | |

