

Micro:Bit Messaging Guide

Key	Action
N	Displays name on Micro:Bit LEDs
P	Sends panic alert to app
G	Requests general help
T	Requests technical help
M	Requests medical help
S	Alerts a safety concern

Press the ‘A’ button to open the message menu. This will open on the key ‘N’.

To go to another message, press the ‘A’ button again.

To send the message related to the key, press button ‘B’.