



Optional jumpers for I2C1
STEM sensors to
connect to Pi or
STM32 (Default)



Optional jumpers to
connect STM32 I2C2
to main board
INA219 sensors

