


slope = slew rate


(a)



output if
not slew-rate
limited

slope = slew rate

(b)



Slope limited by op-amp
maximum slew rate