



Disconnect VCC



Set Vcc to 5V
Connect Vin of Target to Target-VCC
Connect GND to GNDPWR

Disconnect GND



Set Vcc to 5V
Connect GND of Target to Target-GND
Connect GND to GNDPWR

Jonas Scharpf
brainelectronics

Sheet: /
File: MOSFET-Switch.sch

Title: MOSFET Switch

Size: A4 Date: 2020-10-25
KiCad E.D.A. kicad 4.0.7-e2-637658ubuntu16.04.1

Rev: 0.1.0
Id: 1/1