


Default Padstyle: EX60Y60D40P
1st Mtg Padstyle: EX80Y80D50P
2nd Mtg Padstyle: EX70Y70D70P
3rd Mtg Padstyle: EX70Y70D70P
Left Mtg Padstyle: EX60Y60D30P
Right Mtg Padstyle: EX60Y60D30P
Alt Padstyle 1: 0X60Y90D30P
Alt Padstyle 2: 0X90Y60D30P



Default Padstyle: EX60Y60D40P
1st Mtg Padstyle: EX80Y80D50P
2nd Mtg Padstyle: EX70Y70D70P
3rd Mtg Padstyle: EX70Y70D70P
Left Mtg Padstyle: EX60Y60D30P
Right Mtg Padstyle: EX60Y60D30P
Alt Padstyle 1: 0X60Y90D30P
Alt Padstyle 2: 0X90Y60D30P

