

TRICK: RESET pin is held at 5V when the chip is running and pulled to 0V to signal the AVR to enter into programming mode

