



AVR




LEDs




Connectors

ARDUINO




Remove the battery when connecting an external power supply or FTDI cable !


FTDI



AVR-ISP




Power



Released under the Creative Commons Attribution Share-Alike 3.0 License
<http://creativecommons.org/licenses/by-sa/3.0/>

Designed by Andreas Watterott (Watterott electronic)



vCard_v10
 15.12.2010 20:07:38
 Sheet: 1/1