



Command Mode




enter command mode:
press low Bb and draw air




leave command mode:
Press all three palm keys

Transpose Mode




enter transpose mode:
Press low B and draw air



leave transpose mode:
Press all three palm keys

When in command mode: scroll through the sounds



When in transpose mode: select transpose key

