

ZWANZIG DREI-
FÜNF ZEHN VIERTEL
NACH VOR HALB ELF
SECHS NEUN
FÜNF ACHT ZWEI DREI
ZEHN SIEBEN VIER
EINS ZWÖLF

A clock face diagram is centered on the page. It consists of a circle with a break at the top and bottom, forming a ring. The numbers are arranged around this central circle in a circular pattern, corresponding to the positions on a clock face. The numbers are: 12 (ZWANZIG), 1 (EINS), 2 (ZWEI), 3 (DREI), 4 (VIER), 5 (FÜNF), 6 (SECHS), 7 (SIEBEN), 8 (ACHT), 9 (NEUN), 10 (ZEHN), 11 (ELF), and 12 (ZWANZIG). The word 'DREI-' is placed between 'ZWANZIG' and 'DREI' at the 12 o'clock position. The word 'FÜNF' is placed between 'ZEHN' and 'VIERTEL' at the 1 o'clock position. The word 'NACH' is placed between 'VOR' and 'HALB' at the 2 o'clock position. The word 'SECHS' is placed between 'FÜNF' and 'NEUN' at the 3 o'clock position. The word 'FÜNF' is placed between 'ACHT' and 'ZWEI' at the 4 o'clock position. The word 'ZEHN' is placed between 'SIEBEN' and 'VIER' at the 5 o'clock position. The word 'EINS' is placed between 'ZWEI' and 'ZWÖLF' at the 6 o'clock position.