



[[Main operation]]

[[File name ==> pnpActionMainDispatch.pnml]]


[[=====]]




[[retry : call service to controller]
 [[status code: hold status / 9_001]]
 [[File name ==> pnpCarControllerRetry.pnml]]
 [[=====]]




[[none / unknow operation]
 [[status code: 0 / 1]]
 [[File name ==> pnpCarNone.pnml]]
 [[=====]]



[[unknow / initpose operation]
 [[status code: 0 / 1 / 9_001 / 9_101]]
 [[File name ==> pnpCarUnknow.pnml]]
 [[=====]]







[[-----]]

=====]]

=====]]



```
[[File name ==> pnpCarManual.pnml ]]
```




[[=====]]

```
=====]]
```

```
=====]]
```

[[=====]]



```
[[-----]]
```

=====]]

