



For whatever Reason Labels for GND and RST are swapped in Schematics for RFID Module.

Change the following two lines in Keyboard\_RFID\_DE.ino (RGB LED Version) Sketch:

```
#define OLED 18
```

```
const byte buttonPin = 19;
```

Projekt	Klonk		
Datename	klonk.fzz	Revision	
Datum	05 Nov. 2016 11:30:58	Blatt	2/1