

X-230 User Manual

Please read carefully before use this mini copter, because different control board have different operations, So this instructions just explain how to assembly this copter.

Specifications:

Length: 230mm

Width: 230mm

Weight: 350g (ARF)

According to the different purpose, They have different configuration, So you can choose different propeller, ESC and Motor. Our recommendatory configuration as below:

Motor: 1800KV 2222

ESC: 12A

Propeller : 5030X3

Battery : 11.1V 1000-1500mah










Safety Precautions:









- ★ This electric R/C model plane is not a toy.
- ★ Skill level is designed for the intermediate pilot with some flying and building experience.
- ★ Children younger than 14 years old must use it accompanied by an adult.
- ★ Please choose an open place to fly away from buildings and overhead power lines.
- ★ Please always put safety first and operate in a safe and reasonable manner.

The battery must be fully charged before attempting to fly this model.

Important Safety Note:

When charging the battery, it is important to keep battery and charger under observation and never to leave them unattended. Disconnect the battery from the charger when it has finished charging.

<h1>In Box</h1>		M3		x8
CR2301		M3x10+6		x8
CR2302		M3x8		x32
CR2303		M3x18		x12
CR2304		M3x30+6		x8

2222 Motor		x4	12A ESC		x4
2.0mm Gold Plated Connector		x8	ESC Solder Board		x1
T Plug		x1	20X150 Band		x1
GWS 5030		x2	GWS 5030R		x2

