



TABLE OF CONTENTS

► [Home.md](#)

---


# Home.md

## Installation


Install through Card Installer.exe. About 50 MB harddrive space is needed. Matlab Runtime 2024 or Matlab R2024 is required.

## Manual


- Use the load button to import measurements either from the FASTM based setup or the Arduino based setup.



- The rollin mean and downsampling settings can be used to resize the data.



- When using the Arduino mode the measurement traces can be changed through the LED setting.



- Bulk mode can be used to convert all measurements in a single folder.