

IDomain::open

CPU core  
in power-on  
reset?

YES

CPU core is available,  
monitor can be started

NO

Signature  
value found?

YES

CPU core is under  
Bmboot control

NO

CPU core is  
deemed unavailable

