



# Cross Section of Canopy and Lines



The completed annular should be symetrical, each gore seam has a main line and vent pull down line.

## Gore Dimensions



To find the main line insert point measure down the main line from the canopy edge.

Dimensions from the calculator do not include any seam allowance or any line connection allowance, design your patterns accordingly.

