













THE CURRENT OF DC_3V3_D ON WORKING IS 800MA




THE CURRENT OF DC_3V3_A ON WORKING IS 800MA

















TEC A&B&C&D CURRENT ON WORKING IS 8A





















PT100传感器接线
传感器线序:白 红 红
白-->A
红-->ALL
红-->B




THE CURRENT OF DC_5V ON WORKING IS 2A


The power DC_12V can be supply with the other power
the max input voltage is 24V




THE CURRENT OF DC 12V ON WORKING IS 32A



THE CURRENT ON WORKING IS 8A



THE CURRENT ON WORKING IS 8A



THE CURRENT ON WORKING IS 8A

