


Seq S/H Wiring

(Uses Atmel 328P Processor)



For MCP4921 use - jump "DAC LINK" to use external DAC, DAC output should go to RIGHT DACLINK pin. omit 4921 IC.