











DC LTG DIST 1  
A602A22  
A00962-001

A4 0-5 VDC OVHCNSL  
J1  
A 28 VDC IN  
B 28 VDC RTN  
D 0-5 VDC CONTROL  
C 0-5 VDC OUT

A6 0-5 VDC STK POSN  
J1  
A 28 VDC IN  
B 28 VDC RTN  
D 0-5 VDC CONTROL  
C 0-5 VDC OUT





