



NOTE: RST (IO16) is a shared pin with the ULN2803.

The RST line is dedicated to providing a reset function to peripherals that need it.

The ULN2803 is essentially used to multiplex the reset line and provide 8 more reset connections.



CyGate4 I/O Break-out adapter			
Project	CyGate4 - I/O Breakout		
Filename	IO Breakout.fzz	Rev	1.1
Date	03 Jan 2021 10:24:17	Sheet	1/1