

# Samsung J510H Home screen settings

Set your phone's Home screens to fit your needs with this simple guide.

- 1 [Wallpaper settings](#)
- 2 [Widgets settings](#)
- 3 [Theme settings](#)
- 4 [Screen grid settings](#)
- 5 [Adding a new screen](#)


**i** Screenshot examples are made on Android 6.0-operated Samsung phone. For other versions of Android user interface look and functions may vary. [Contact us](#) for Support Team member assistance.

1. Press an **On/Off** button to unlock your phone's screen. Input your password or draw a visual password if needed
2. Press a **Home** button of your phone and then press it again to center on a default Home screen. You'll see a house pictogram in the lower part of the screen highlighted
3. Tap any blank space on your screen and hold until Home screen settings appear



## Wallpaper settings

1. Select **Wallpapers** from a Home screen settings menu to choose the wallpapers for a Lock screen and a Home screen



2. Select **Home Screen** to apply your wallpaper to Home screen, Lock screen or both
3. Select a wallpaper you like and tap **SET AS WALLPAPER**

#### Widgets settings

1. Select **Widgets** from a Home screen settings menu.



2. Widgets may come as a group or as a single icon. If there's a group, tap it to open the list of widgets in this group.



3. Select a widget and hold it until your Home screen appears. Drag a widget towards a place of your choice (a border of a widget will light the designated place up). If you picked a wrong widget, drag it up to a **Cancel** button until a button lights up—and drop a widget.




4. Drop a widget onto a chosen place.



Theme settings

1. Select **Themes** from a Home screen settings menu



2. Tap **MORE THEMES** to browse for downloadable themes if needed or select any of the available themes

Screen grid settings

1. Select **Screen Grid** from a Home screen settings menu



2. Select a grid layout you like



3. Tap **APPLY**

Adding a new screen

1. Click to the left from a Home screen settings menu



2. Tap a **plus sign**



3. Tap a **Back** button of your phone to exit Home screen settings menu