



USB Programmer

avrISP@megaCore Series
ATmega64, 128~6490
usbAsp_Serials.sch




MISO=PDO/TX
MOSI=PDI/RX

microUPDI@megaCoreX Series
ATmega808~4809
usbAsp_Serials.sch



jtag2UPDI@megaTiny/tinyAVR Series
ATtiny202, 402~3227 Series
jtag2updim.sch



stm32duino@STM32 Series
STM32 Series
stLink4.sch

