



### 3 Spray Modes

One switch button makes it easy to switch between 3 spray modes.



To set rainfall spray mode, turn the dial clockwise so it points downward.



To set rainfall +handheld spray mode, turn the dial so it points toward the middle.



To set handheld spray mode, turn the dial counter-clockwise so it points upward.



