





TeeShirt

Ergonomic Monoblock Keyboard



Base Layer (0)





Symbol Layer (1)



Number Layer (2)





Extra Layer (3)









Boot will place the keyboard in bootloader mode which allows you to flash new firmware. To exit this mode, unplug and plug the keyboard back in.


Layer Lock



Locking a layer will key your keyboard on that layer without holding down any layer keys. To unlock, simply scroll back to layer 0.



Remap Keys with Vial



<https://get.vial.today>